



Using instruction:

To extend the longevity of product, please read this instruction carefully before use:

 X Don't spray chemicals like pesticide on the surface.	 X Don't wipe the sofa with corrosive solution.	 X Avoid direct sunlight.	 ○ Use leather cleaner or white towel with a little alcohol to wipe out stains.	 ○ Use a wring-out towel or household vacuum cleaner for daily maintenance.
 X Keep a distance of at least 50cm from hot items and maintain smooth ventilation.	 X Avoid peeling on the sofa or sitting on the sofa directly when sweating.	 X Don't stand on the sofa, which may cause fracture and hollow.	 X Don't disassemble the product on your own if there is any problem.	 X Please contact after-sales service if there is any problem not covered in the table below.


Solution to small issues:

Malfunction	Reason	Solution
The sofa is not stable	Uneven ground	Cushion the bottom of sofa with some hard material
Accessories move inflexibly	Loose connection or lack lubricating oil	Tighten the screws and add some lubricating oil
Creaking sound	The sofa feet rubs with ground	Place leather cushion beneath sofa feet
Crumpled surface	Squeeze during transportation	Gently pat on the leather/fabric surface to restore the outlook


Assembly instruction:


- Please determine the location of your furniture before assembly to avoid moving them for a large distance after being assembled.
- Do not place your furniture in dark and damp or hot and dry environment.
- Please check the number of packaging bags, view the product installation manual and verify the product structure.
- Please check the direction of each part when unpacking them before installation.
- Please install the product patiently. Make sure each part is in the right position. Furniture is easy to assemble, but it needs patience and care to make every part in place.
- Please check the stability of the furniture after installation. Shake your furniture gently to confirm whether it is level with the ground or whether the screw is tight.
- Please keep the furniture open for a period of time to release residual painting smell.

Note :









① At least two people are required.

③ Contact Sunon if you have any confusions.

Sunon 圣奥

Using instruction

Product introduction

Thanks for buying this product.
Please read this instruction
carefully before use.

Name: SF47.1 MX W
Model: Hua er II series
Dimension : 590*630*880*450mm
Material: Use of high-quality cleats, leather, fabric, metal fee


This product is for office,decoration ,indoor use.

Sunon Technology Co., Ltd.

Service Hotline: 4008-600-666

Website: www.sunonglobal.com




Headquarters: Sunon Central Business Building, No. 200
Citizen Street, Qianjiang CBD, Hangzhou, Zhejiang
Manufacturing Base:No.5806 Qingxi 3rd road, Qiantang
District, Hangzhou, Zhejiang, China



Material :

Material	Genuine leather	Premium leather, lustrous, airy, soft and resilient
	Water-based leather/EPU	Colorful and diversified.
Filling	Hemp soft cloth/polyester	Flame retardant, stain resistant and not easily deformed.
	Resilient foam	Of appropriate hardness.
	Latex foam	Made of natural latex, high elasticity, shock absorption, good load-bearing, comfortable and durable.
	PP foam	Comfortable touch, smooth and soft, flexible and well-shaped.
	Silk wadding	Even and smooth.
	Duck down	Good quality, resilient and able to contract and expand as temperature changes.
	Solid wood	Top quality natural larch wood, moisture content ≤ 12%.
	Artificial panel	Not easily deformed, safe and eco-friendly.
	Spring	Snake-shaped spring steel wire with a diameter of 3.0mm-4.0mm highlights stable elasticity.
	Reinforced steel wire	4.0mm-6.0mm diameter ensures higher elasticity and durability.
Other materials	Beveled wood piece	The paint has great resistance to heat and impact.
	Hardware	Premium (A-grade) accessory, lightweight, durable and safe.



Dimension:



Assembly instruction:

No further notice will be given with regard to changes.

List of assembly accessories

a		b		c		d	
e		f					

2.将气杆插入
f

a

3.将5个脚轮安装卡紧
b

e

d

1. 用4颗内外六角螺钉
(M8*20) 连接座垫和托盘