
Sunón

CHF80SW Assembly Instructions




This manual is applicable to the installation of CHF80SW. Please read this manual carefully before use and keep it in a safe place.


Installation Notes




Handle with care and use protective padding when necessary.



② Secure transportation requires assistance from two persons.




 $\begin{cal}{c} \begin{cal} \$



The manual indicates the components included with this product, with some parts considered as critical components.

If the parts displayed here do not match your order, please contact Sunon at +86-400-8600-666.

Exploded Diagram




No	Name	Quantity	
1	Chair body	1	
2	Armrest	2	
3	Gas Cylinder	1	
4	Five-Star Base	1	
5	Chair Casters	5	


Accessory List

A			B			
Countersink socket head screw	M8*25	4	wrench	5#	1	

1. caster inserted into five-star base



1. Flip the chair body over, align the hole positions, and use M8*25 countersunk hex screws to secure it.



1. Insert the gas rod into the tube in the five-star base, then insert the conical hole in the seat base into the top end of the gas rod.






Functional Description

1. Adjust seat height

Upward: Rise up and push the right wire handle outward to controll the mechanism and raise the seat to a comfortable height;

Downward: Pull the right wire handle outward to control the mechanism and lower the seat to a comfortable height.



2. Adjust tension controller n the initial horizontal state, pull the left wire control handle outward to unlock, and continue to pull the handle outward to lock.



2

Acceptance Notes

